WASHING MACHINE 洗衣機 MESIN BASUH

INSTRUCTION BOOKLET 説 明 手 册 BUKU PETUNJUK



EWF 549 EWF 551









Dear customer,

Please read these operating instructions carefully and pay particular attention to the safety notes indicated in the first pages. We recommend that you keep this instruction booklet for future reference and pass it on to any future owners.

Transport damages

When unpacking the appliance, check that it is not damaged. If in doubt, do not use it and contact the Service Centre.

The symbols you will see on some paragraphs of this booklet have the following meaning:



The warning triangle and/or the key words (Warning!, Caution!) emphasize information that is particularly important for your safety or correct functioning of the appliance.



The information marked with this symbol provides additional instructions and practical tips on the use of the appliance.



Tips and information about economical and ecological use of the machine are marked with this symbol.

Our contribution to the protection of the environment: we use environmentally friendly paper.

Contents

Warnings	3	Washing hints	9
		Sorting the laundry	9
Disposal	4	Temperatures	9
Tips for environmental protection	4	Before loading the laundry Maximum loads	9
Technical specifications	4	Laundry weights Removing stains	9
	5	Detergents and additives Operating sequence	10 11-12
Unpacking Positioning Water inlet	5 5 5	International wash code symbols Washing programmes	13 14-15
Water drainage Electrical connection	6 6	Maintenance Door seal	16
Your new washing machine	7	Bodywork Detergent dispenser drawer	16 16
Description of the appliance	7	Drain pump	16-17
Detergent dispenser drawer	7	Water inlet filter Emergency emptying out	17 17
Use	8	Frost precautions	17
Control panel Controls	8	Something not working?	18-19

⚠ Warnings

The following warnings are provided in the interests of overall safety. You must read them carefully before installing or using the appliance.

Installation

- All internal packing must be removed before using the appliance. Serious damage may be caused to the machine or adjacent furniture if the protective transit devices are not removed or are not completely removed.
 Refer to the relevant paragraph in the instruction
- Refer to the relevant paragraph in the instruction book.
- Any electrical work required to install this appliance must be carried out by a qualified electrician.
- Any plumbing work required to install this appliance must be carried out by a qualified plumber.
- After having installed the machine, check that it is not standing on its electrical supply cable.
- If the appliance is placed on a carpeted floor, ensure that air can circulate freely between the feet and the floor.

Use

- This appliance is designed for domestic use. It must not be used for purposes other than those for which it was designed.
- Only wash fabrics which are designed to be machine washed. Follow the instructions on each garment label.
- Do not overload the appliance. Follow the instructions in the instruction book.
- Make sure that all pockets are empty. Objects such as coins, safety pins, pins and screws can cause extensive damage.
- Do not machine wash garments saturated with petroleum, methylated spirits, trichlorethylene, etc. If such fluids have been used to remove stains prior to washing, wait until they have completely evaporated from the fabric before placing garments in the appliance.
- Place small items such as socks, belts, etc. in a cloth bag or pillowcase to prevent them getting trapped between the drum and the tub.

- Use only the recommended quantities of fabric softener. An excessive amount could damage the laundry.
- Leave the porthole door slightly ajar when the appliance is not in use. This preserves the door seal and prevents the formation of musty smells.
- Always check that water has emptied out before opening the door. If not, drain the water following the instructions in the instruction book.
- Always unplug the appliance and shut the water tap after use.

General safety

- Repairs to the machine must be carried out only by qualified personnel. Repairs carried out by inexperienced persons could cause serious danger. Contact your local Service Centre.
- Never pull the power supply cable to remove the plug from the socket; always take hold of the plug itself.
- During high temperature wash programmes the door glass may get hot. Do not touch it!

Child safety

- Children are often not aware of how dangerous electrical appliances can be. When the machine is working, children should be carefully supervised and not be allowed to play with the appliance.
- The packaging components (e.g. plastic film, polystyrene) can be dangerous to children danger of suffocation! Keep them out of children's reach.
- Keep all detergents in a safe place out of children's reach.
- Make sure that children or pets do not climb into the drum.
- When the appliance is to be scrapped, cut off the electrical supply cable and destroy the plug with the remaining cable. Disable the door catch in order to prevent children from becoming trapped inside while playing.



Packaging materials

The materials marked with the symbol \circlearrowleft are recyclable.

- >PE<=polyethylene
- >PS<=polystyrene
- >PP<=polypropylene

This means that they can be recycled by disposing of

them properly in appropriate collection containers.

Machine

Use authorised disposal sites for your old appliance. Help to keep your country tidy!

Tips for environmental protection

To save water, energy and to help protect the environment, we recommend that you follow these

- Normally soiled laundry may be washed without prewashing in order to save detergent, water and time (the environment is protected too!).
- The machine works more economically if it is fully loaded.
- · With adequate pre-treatment, stains and limited soiling can be removed; the laundry can then be washed at a lower temperature.
- · Measure out detergent according to the water hardness, the degree of soiling and the quantity of laundry being washed.

Technical specifications

DIMENSIONS	Height Width Depth	85 cm 60 cm 59 cm	
MAXIMUM LOAD	Cotton	5	kg
	Synthetics	2	kg
	Delicates	2	kg
	Woollens	1	kg
SPIN SPEED		550 rp	m max.
POWER SUPPLY VOLTAGE/FREQUENCY TOTAL POWER ABSORBED MINIMUM FUSE PROTECTION			40 V/50 Hz N (EWF 551) / 400W (EWF 549)
WATER PRESSURE	Minimum Maximum	50 kF 800 kF	



This appliance complies with the following EEC Directives: 73/23/EEC of 19/02/73 relating to low voltage 89/336/EEC of 03/05/89 relating to electromagnetic compatibility.

Installation

Unpacking




All transit bolts and packing must be removed before using the appliance.


You are advised to keep all transit devices so that they can be refitted if the machine ever has to be transported again.


 Using a spanner, unscrew and remove the two rear bottom screws. Slide out the two plastic pins. Lay the machine on its back, taking care not to squash the hoses. This can be avoided by placing one of the corner packing pieces between the machine and the floor.






- 2. Remove the polystyrene block(s) from the bottom of the machine and release the two plastic bags.
- 3. Very carefully slide out the left polythene bag, removing it towards the right and then downwards.







4. Very carefully slide out the right polythene bag, removing it towards the left and then upwards. Remove the bottom cover placed into the drum of your appliance, lay it's hook as the arrow 'A' indicates and push the top of the cover to seal it closed


Important: You can find more detailed instructions regarding the bottom cover assembling in it's relative bag.





- 5. Set the machine upright and remove the remaining rear screw. Slide out the relevant pin.
- 6. Plug all the holes with the plugs which you will find in the envelope containing the instruction manual.






Positioning

Install the machine on a flat hard floor.

Make sure that air circulation around the machine is not impeded by carpets, rugs etc. Check that the machine does not touch the wall or cupboard units. Carefully level by screwing the adjustable feet in or out. Never place cardboard, wood or similar materials under the machine to compensate for any unevenness in the floor.




Water inlet

Connect the water inlet hose to a tap with 3/4" BSP thread.

Use the hose supplied with the washing machine. DO NOT USE OLD HOSES.

The other end of the inlet hose which connects to the machine can be turned in any direction. Simply loosen the fitting, rotate the hose and retighten the fitting, making sure there are no water leaks.





The inlet hose must not be lengthened. If it is too short and you do not wish to move the tap, you will have to purchase a new, longer hose specially designed for this type of use.

Important!


Before connecting up the machine to new pipework or to pipework that has not been used for some time, run off a reasonable amount of water to flush out any debris that may have collected in the pipes.

Water drainage

The end of the drain hose can be positioned in three ways:

Hooked over the edge of a sink using the plastic hose guide supplied with the machine. In this case, make sure the end cannot come unhooked when the machine is emptying.

This could be done by tying it to the tap with a piece of string or attaching it to the wall.




In a sink drain pipe branch. This branch must be above the trap so that the bend is at least 60 cm above the ground.

Directly into a drain pipe at a height of not less than 60 cm and not more than 90 cm.

The end of the drain hose must always be **ventilated**, i.e. the inside diameter of the drain pipe must be larger than the outside diameter of the drain hose.

The drain hose must not be kinked.



For a correct functioning of the machine the drain hose must remain hooked on the proper support piece situated on the top part of the back side of the appliance.

Electrical connection

This machine is designed to operate on a 230-240 V, single-phase, 50 Hz supply.

Check that your domestic electrical installation can take the maximum load required (2.05 kW), also taking into account any other appliances in use.

Connect the machine to an earthed socket.




WARNING: THIS APPLIANCE MUST BE EARTHED.

In the event of having to change the fuse in the plug supplied, a 13 amp. ASTA approved (BS1363A) fuse must be used.

Should the plug need to be replaced for any reason, proceed as described below.

The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow - Earth
Blue - Neutral
Brown - Live



The wire coloured green and yellow must be connected to the terminal marked with the letter «E» or by the earth symbol $\stackrel{\bot}{=}$ or coloured green and yellow.

The wire coloured blue must be connected to the terminal marked «N» or coloured black.

The wire coloured brown must be connected to the terminal marked «L» or coloured red. Upon completion there must be no cut, or stray strands of wire present and the cord clamp must be secure over the outer sheath.



WARNING:

A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard. Ensure that the cut off plug is disposed of safely.

Please ensure that when the appliance is installed the power supply cable is easily accessible.


Your new washing machine

This new machine meets all modern needs for effective treatment of laundry with low water, energy and detergent consumption.

- The temperature selector dial will allow you to choose the most suitable temperature for your laundry.
- The **automatic cooling of the washing water** from 95° to 60°C before draining will prevent old drain pipes from being deformed and will reduce thermal shock to fabrics, helping to prevent creasing.
- The special wool programme with its new delicate wash system treats your woollens with extreme care.
- The unbalance control device ensures the machine is stable during the spin.
- The ECO valve allows total use of detergent and reduces water consumption so saving energy.

Description of the appliance

- 1. Detergent dispenser drawer
- 2. Programme chart
- 3. Control panel
- 4. Door handle
- 5. Drain pump
- 6. Adjustable feet




Detergent dispenser drawer

Pre-wash


Main wash

Rabric softener, starch



Use

Control panel



1. Detergent Dispenser Drawer

2. "Start /Add Clothes" Button

After having selected the programme and the required options, press this button to start the machine. The corresponding LED stops flashing and remains lit. To interrupt a programme which is running, depress the Start/Add Clothes button, the corresponding LED starts to flash. To restart the programme from the point at which it was interrupted, press the Start/Add clothes button again.

3. "Quick Wash"

Pressing this button, will shorten the selected wash program. As an example, if this button is pushed, the LED will light up and the program 'Automatic' will be reduced to approx. 60 min from 110 min.

4. Programme Selector Dial

OFF, COLD for EWF 549 and OFF, HOT and COLD for EWF 551

This can be rotated in clockwise and anti clockwise direction.

At the end of the programme the selector dialmust be turned to position "O" to switch the machine off. Attention! If during a wash programme, the selector dial is turned to another programme, the machine will not perform the new selected programme.

In the EWF 551 for HOT programs the temperature is preset (Refer page 14).

Washing hints

Sorting the laundry

Follow the wash code symbols on each garment label and the manufacturer's washing instructions. Sort the laundry as follows:

whites, coloured, synthetics, delicate, woollens.

Before loading the laundry

Never wash whites and coloured together. Whites may lose their "whiteness" in the wash.

New coloured items may run in the first wash; they should therefore be washed separately the first time.

Make sure that no metal objects are left in the laundry (e.g. hair clips, safety pins,.

Button up pillowcases, close zip fasteners, hooks and poppers. Tie any belts or long tapes. Remove persistent stains before washing. Rub particularly soiled areas with a special detergent or detergent paste.

Treat curtains with special care. Remove hooks or tie them up in a bag or net.

Maximum loads

Recommended loads are indicated in the programme charts.

General rules:

Cotton, linen: drum full but not too tightly packed;

Synthetics: drum no more than half full;

Delicate fabrics and woollens: drum no more than one third full.

Washing a maximum load makes the most efficient use of water and energy.

For heavily soiled laundry, reduce the load size.

Laundry weights

The following weights are indicative:

bathrobe	1200 g
napkin	100 g
quilt cover	700 g
sheet	500 g
pillow case	200 g
tablecloth	250 g
towel	200 g
tea cloth	100 g
night dress	200 g
ladies' briefs	100 g
man's work shirt	600 g
man's shirt	200 g
man's pyjamas	500 g
blouse	100 g
men's underpants	100 g

Removing stains

Stubborn stains may not be removed by just water and detergent. It is therefore advisable to treat them prior to washing.

Blood: Treat fresh stains with cold water. For dried stains, soak overnight in water with a special detergent then rub in the soap and water.

Oil based paint: Moisten with benzine stain remover, lay the garment on a soft cloth and dab the stain; treat several times.

Dried grease stains: Moisten with turpentine, lay the garment on a soft surface and dab the stain with the fingertips and a cotton cloth.

Rust: Oxalic acid dissolved in hot water or a rust removing product used cold. Be careful with rust stains which are not recent since the cellulose structure will already have been damaged and the fabric tends to hole.

Mould stains: Treat with bleach, rinse well (whites and fast coloureds only).

Grass: Soap lightly and treat with bleach (whites and fast coloured only).

Ball point pen and glue: Moisten with acetone (*), lay the garment on a soft cloth and dab the stain. **Lipstick**: Moisten with acetone as above, then treat stains with methylated spirits. Remove any residual marks from white fabrics with bleach.

Red wine: Soak in water and detergent, rinse and treat with acetic or citric acid, then rinse. Treat any residual marks with bleach.

Ink: depending on the type of ink, moisten the fabric first with acetone (*), then with acetic acid; treat any residual marks on white fabrics with bleach and then rinse thoroughly.

Tar stains: first treat with stain remover, methylated spirits or benzine, then rub with detergent paste.

(*) do not use acetone on artificial silk.

Detergents and additives

Good washing results also depend on the choice of detergent and use of the correct quantities to avoid waste and protect the environment. Although biodegradable, detergents contain substances which, in large quantities, can upset the delicate balance of nature.

The choice of detergent will depend on the type of fabric (delicate, woollens, cottons, etc.), the colour, washing temperature and degree of soiling.

All commonly available washing machine detergents may be used in this appliance:

- powder detergents for all types of fabric,
- powder detergents for delicate fabrics (60°C max) and woollens,
- liquid detergents, preferably for low temperature wash programmes (60°C max) for all types of fabric, or special for woollens only.

The detergent and any additives must be placed in the appropriate compartments of the dispenser drawer before starting the wash programme.

If concentrated powder or liquid detergents are used, programme **without** pre-wash must be selected.

The washing machine incorporates a recirculation system which allows an optimal use of the concentrated detergent.

Pour liquid detergent into the dispenser drawer compartment marked **just before** starting the programme.

Any fabric softener or starching additives must be poured into the compartment marked **before** starting the wash programme.

Follow the product manufacturer's recommendations on quantities to use and do not exceed the «MAX.» mark in the detergent dispenser drawer.

Quantity of detergent to be used

The type and quantity of detergent will depend on the type of fabric, load size, degree of soiling and hardness of the water used.

Water hardness is classified in so-called "degrees" of hardness. Information on hardness of the water in your area can be obtained from the relevant water supply company, or from your local authority.

Follow the product manufacturers' instructions on quantities to use.

Use less detergent if:

- you are washing a small load,
- the laundry is lightly soiled,
- large amounts of foam form during washing.

i Operating sequence

Before the first wash we recommend that you pour 2 litres of water into the main wash compartment USECO valve. Then run the automatic cycle with the machine empty, in order to remove any manufacturing residue from the drum and tub. Pour half a measure of detergent into the main wash compartment and start up the machine.

1. Place the laundry in the drum

Open the door.

Place the laundry in the drum, one item at a time, shaking them out as much as possible.
Close the door.





2. Measure out the detergent

If you wish to carry out the pre-wash, pour detergent into the appropriate compartment marked $\ensuremath{\bigsqcup}$.

3. Measure out the additive


If required, pour fabric softener into the compartment marked $\ \otimes\$, without exceeding the «MAX» mark.






4. Select the desired programmes

Turn the programme selector dial to the desired position.






EWF 551

EWF 549

The LED corresponding to the **Start / Add clothes** button starts to flash.

5. Select the option "Quick Wash" if required


The LED corresponding to the **Quick Wash** button illuminates



6. Start the machine

Push the **Start / Add clothes** button and the programme starts

The LED corresponding to the **Start/ Add clothes** button illuminates



7. At the end of the programme

The machine stops automatically and the **Start/Add clothes** button LED goes off.

If you have selected the **Quick Wash** button, LED for the button will also go off.

Wait one or two minutes before opening the door to give the electric locking mechanism time to release it.

Remove the laundry.


Turn the drum by hand to make sure it is completely empty, so as to avoid any forgotten items being damaged in a subsequent wash (e.g. shrinking) or their colour running into a load of whites.

Turn the water tap off and unplug the machine. Leave the door open for the tub to dry.


Do not


wash

i International wash code symbol









These symbols appear on fabric labels, in order to help you choose the best way to treat your laundry.

EWF 551 - Hot Programmes

The temperature of each programme is pre defined and is set automatically Depending upon the type of laundry and is as per the selected programme.

Programme	Type of laundry and degree of soil	Programme	Programme description	Possible option
A	Houselhold, linens, sheets, shirts, under garments	Automatic	Wash 40°, 3 rinses, normal spin	Quick Wash
В	Jeans, hand towels, sheets, table clothe	Jeans / Towels	Pre-Wash 40°, Wash 60°, 5 rinses, maximum spin	Quick Wash
С	Shirts, blouses, easy to iron	Easy Iron	Wash 40°, 3 rinses, gentle spin	Quick Wash
D	Delicate, for. e.g. curtains	Delicate	Wash 30°, 3 rinses, gentle spin	Quick Wash
E	Clothes labelled "Pure new wool, non-shrink machine washable" & silk fabrics	Wool and silk	Wash 30°, 3 rinses, normal spin	Quick Wash
EWF 551 -	Cold Programme	S		
F	Fast coloured cottons like towels, Non fast colured clothes like under garments, shirts.	Colour cottons	Wash, 3 rinses, normal spin	Quick Wash
G	Acrilic, viscose, polyester, curtains	Synthetics	Wash, 3 rinses, gentle spin	Quick Wash
Н	Shirt, blouses, undergarments, mixed fabrics	Hand Wash	Wash, 3 rinses, gentle spin	Quick Wash
I		Rinse	3 rinses, drain normal spin	
J		Drain	Drain	
к		Spin	Normal spin	

Note: Normal spin is 500 rpm. , gentle spin is 450 rpm. and max spin is 550 rpm.

Programme table

EWF 549

Programme	Type of laundry and degree of soil	Programme	Programme description	Possible option
A	Houselhold , linens, sheets, shirts, under garments	Automatic	Pre-Wash, wash, 5 rinses, normal spin	Quick Wash
В	Shirts, table clothes, undergarments	Daily cotton	Wash , 3 rinses, normal spin	Quick Wash
С	Delicates like pillow covers, curtains	Delicate colour	Wash , 3 rinses, normal spin	Quick Wash
D	Easy to iron,shirts, blouses	Easy iron	Wash , 3 rinses, normal spin	Quick Wash
E	Acrylic,viscose, polyester,curtains	Synthetics	Wash , 3 rinses, gentle spin	Quick Wash
F	Clothes labelled "Pure new wool, non shrink machine washble" & silk fabrics	Wool and silk	Wash , 3 rinses, normal spin	
G	Shirt, blouses, undergarments, mixed fabrics	Hand Wash	Wash , 3 rinses, gentle spin	
н		Softner	1 rinse, normal spin	
1		Rinse	3 rinses, drain normal spin	
J		Drain	Drain	
К		Spin	Normal spin	

Note: Normal spin is 500 rpm. and gentle spin is 450 rpm.

Maintenance

1.Cleaning the Door Seal

Check from time to time the door seal and eliminate eventual possible objects that could be trapped in the fold.



2.External Cleaning

Clean the outside of the machine with warm water znd a detergent used to handwash dishes. Rinse with clean water and dry with a soft cloth.


Important: do not use methylated spirits, solvents or similar products to clean the bodywork.


3. Cleaning the Detergent Drawer

After a while, detergents and fabric softeners leave deposits in the drawer.


Clean the drawer from time to time by rinsing it under a running tap. To remove the drawer from the machine, press the button in the rear left-hand corner.

To facilitate cleaning, the top part of the additive compartments can be removed.





Detergent can also accumulate inside the drawer recess: clean it with an old toothbrush. Refit the drawer after cleaning.




4. Cleaing Drain Pump

The pump should be inspected regularly and particularly if


- the machine does not empty and/or spin
- the machine makes an unusual noise during draining due to objects such as safety pins, coins etc. blocking the pump.

Proceed as follows:

- Disconnect the appliance.
- If necessary wait until the water has cooled down.
- Open the pump door.



- Place a container close to the pump to collect any spillage.
- Release the emergency emptying hose, place it in the container and remove its cap.
- When no more water comes out, unscrew the pump and remove it. Always keep a rag nearby to dry up spillage of water when removing the pump.



• Remove any objects from the pump impeller by rotating it.



• Put the cap back on the emergency emptying hose and place the latter back in its seat.



- Screw the pump fully in.
- Close the pump door.

5. Water inlet filter

If you notice that the machine is taking longer to fill, check that the filter in the water inlet hose is not blocked.

Turn off the water tap.

Unscrew the hose from the tap. Clean the filter with a stiff brush. Screw the hose back onto the tap.



6. Emergency emptying out

If the water is not discharged, proceed as follows to empty out the machine:

- pull out the plug from the power socket;
- · close the water tap;
- if necessary, wait until the water has cooled down;
- open the the pump door;
- place a bowl on the floor and place the end of the emergency emptying hose into the bowl. Remove its cap. The water should drain by gravity into the bowl. When the bowl is full, put the cap back on the hose. Empty the bowl. Repeat the procedure until water stops flowing out;
- clean the pump if necessary as previously described;
- replace the emergency emptying hose in its seat after having plugged it;
- · screw the pump again and close the door.

7. Frost precautions

If the machine is installed in a place where the temperature could drop below 0°C, proceed as follows:

- Remove the plug from the socket.
- Close the water tap and unscrew the water inlet hose from the tap.
 - Place the end of the emergency emptying hose and that of the inlet hose in a bowl placed on the floor and let water drain out.
- Screw the water inlet hose back on and reposition the emergency emptying hose after having put the cap on again.

By doing this, any water remaining in the machine is removed, avoiding the formation of ice and, consequently, breakage of the affected parts.

When you use the machine again, make sure that the ambient temperature is above 0°C. **Important!**

Every time you drain the water through the emergency emptying hose you must pour 2 litres of water into the main wash compartment of the detergent drawer and then run the drain programme. This will activate the ECO valve avoiding that part of the detergent remains unused at next washing.


Something not working?

Problems which you can resolve yourself.


Problem	Possible cause
• The machine does not start up:	 The door is not firmly closed. The machine is not plugged in or there is no power at the socket. The main fuse or the fuse in the plug has blown. The programme selector dial is not positioned correctly. The "Start / Add clothes" button has not been depressed
The machine does not fill:	 The water tap is closed. The inlet hose is squashed or kinked. The filter in the inlet hose is blocked. The door is not properly closed.
 The machine fills then empties immediately: 	The end of the drain hose is too low. Refer to relevan paragraph in "water drainage" section.
The machine does not empty and/or does not spin:	The drain hose is squashed or kinked. The drain pump is clogged.
There is water on the floor:	 Too much detergent or unsuitable detergent (creates too much foam) has been used. Check whether there are any leaks from one of the inlet hose fittings. It is not always easy to see this as the water runs down the hose; check to see if it is damp. The drain hose is damaged. The cap on the emergency emptying hose has not been replaced after cleaning the filter.
Unsatisfactory washing results:	 Too little detergent or unsuitable detergent has been used. Stubborn stains have not been treated prior to washing. The correct temperature was not selected. Excessive laundry load.
The machine vibrates or is noisy:	 The transit bolts and packing have not been removed The support feet have not been adjusted. The laundry is not evenly distributed in the drum. Maybe there is very little laundry in the drum.
• The door will not open:	The programme is still running.The door lock has not been released.There is water in the drum.

Problem Possible cause • Spinning starts late or the laundry is not spun enough: • The electronic unbalance detection device has cut in because the laundry is not evenly distributed in the drum. The laundry is redistributed by reverse rotation of the drum. This may happen several times before the unbalance disappears and normal spinning can resume. If, after few minutes, the laundry is still not evenly distributed in the drum, the machine will not spin. If at the end of the programme the laundry is not spun enough, redistribute the load manually and select the spin programme.


Water is not
visible in the machine. The machine,
which is the result of modern technology, runs
in a very economical way with low water
consumption. Performance is
nevertheless excellent



If you are unable to identify or solve the problem, contact our service centre. Before telephoning, make a note of the model, serial number and purchase date of your machine: the Service Centre will require this information.







From the Electrolux Group. The world's No. 1 choice.

The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, washing machines, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. USD 14 billion in more than 150 countries around the world.